

KENWOOD

INSTRUCTION MANUAL
MODE D'EMPLOI
MANUAL DE INSTRUCCIONES
MANUALE DI ISTRUZIONI
BEDIENUNGSANLEITUNG
GEBRUIKSAANWIJZING



ProTalk
TK-3201

UHF FM TRANSCEIVER
ÉMETTEUR-RÉCEPTEUR FM UHF
TRANSCÉPTOR DE FM UHF
RICETRASMETTITORE FM UHF
UHF-FM-TRANSCEIVER
UHF FM ZENDONTVANGER

Kenwood Corporation

© B62-1980-00 (E2, T2)
09 08 07 06 05 04 03 02 01 00

ProTalk

TK-3201

UHF FM TRANSCEIVER

INSTRUCTION MANUAL

ENGLISH

THANK YOU

We are grateful for your purchase of this **KENWOOD** product and welcome you to the Private Mobile Radio service (PMR 446). PMR is a mobile communication system for both business and personal use without the need for a license and with no call charges.

Your **KENWOOD** 2-way Private Radio is called a “transceiver”, meaning “transmitter & receiver”. We believe this easy-to-use transceiver will provide you with dependable and reliable communications. This **KENWOOD** transceiver is a precision device. Treat it with care, and you will enjoy years of reliable operation.

FEATURES

- 16 channels with 8 operating frequencies and 38 tone/ code settings for each channel allows you to ignore unwanted calls.
- Built in voice scrambler gives you complete privacy for your conversations.
- Hands free operation when using an optional headset.
- Voice announcement lets you know which channel you have selected and which settings you have made when reassigning key functions and channel settings.

OPERATING CONDITIONS

Open locations (no obstructions)	Up to 6.4 km
Residential areas (near buildings)	Up to 2.4 km
In steel/ concrete reinforced buildings	Up to 18,580 m ²
In high rises	Up to 15 floors

Note: The listed ranges are based on field testing and may vary with your operating conditions and individual transceiver.

NOTICES TO THE USER

- ◆ Government law prohibits the operation of unlicensed radio transmitters within the territories under government control.
- ◆ Illegal operation is punishable by fine and/or imprisonment.
- ◆ Refer service to qualified technicians only.

SAFETY: It is important that the operator is aware of and understands hazards common to the operation of any transceiver.

PRECAUTIONS

- Do not charge the transceiver and battery pack when they are wet.
- Ensure that there are no metallic items located between the transceiver and the battery pack.
- Do not use options not specified by **KENWOOD**.
- If the die-cast chassis or other transceiver part is damaged, do not touch the damaged parts.
- If a headset or headphone is connected to the transceiver, reduce the transceiver volume. Pay attention to the volume level when turning the squelch off.
- Do not place the microphone cable around your neck while near machinery that may catch the cable.
- Do not place the transceiver on unstable surfaces.
- Ensure that the end of the antenna does not touch your eyes.
- When the transceiver is used for transmission for many hours, the radiator and chassis will become hot. Do not touch these locations when replacing the battery pack.
- Do not immerse the transceiver in water.
- Always switch the transceiver power off before installing optional accessories.

**WARNING**

Turn the transceiver power off in the following locations:

- In explosive atmospheres (flammable gas, dust particles, metallic powders, grain powders, etc.).
- While taking on fuel or while parked at gasoline service stations.
- Near explosives or blasting sites.
- In aircrafts. (Any use of the transceiver must follow the instructions and regulations provided by the airline crew.)
- Where restrictions or warnings are posted regarding the use of radio devices, including but not limited to medical facilities.
- Near persons using pacemakers.

**CAUTION**

- Do not disassemble or modify the transceiver for any reason.
- Do not place the transceiver on or near airbag equipment while the vehicle is running. When the airbag inflates, the transceiver may be ejected and strike the driver or passengers.
- Do not transmit while touching the antenna terminal or if any metallic parts are exposed from the antenna covering. Transmitting at such a time may result in a high-frequency burn.
- If an abnormal odor or smoke is detected coming from the transceiver, switch the transceiver power off immediately, remove the battery pack from the transceiver, and contact your **KENWOOD** dealer.
- Use of the transceiver while you are driving may be against traffic laws. Please check and observe the vehicle regulations in your area.
- Do not expose the transceiver to extremely hot or cold conditions.
- Do not carry the battery pack (or battery case) with metal objects, as they may short the battery terminals.
- When operating the transceiver in areas where the air is dry, it is easy to build up an electric charge (static electricity). When using a earphone accessory in such conditions, it is possible for the transceiver to send an electric shock through the earphone and to your ear. We recommend you use only a speaker/microphone in these conditions, to avoid electric shocks.

CONTENTS

UNPACKING AND CHECKING EQUIPMENT	1
SUPPLIED ACCESSORIES	1
ORIENTATION	3
PREPARATION	4
BATTERY PACK PRECAUTIONS	4
CHARGING THE BATTERY PACK	8
INSTALLING/ REMOVING THE BATTERY PACK	10
INSTALLING THE BELT CLIP	11
INSTALLING THE COVER OVER THE SPEAKER/ MICROPHONE JACKS	11
INSTALLING THE OPTIONAL SPEAKER/ MICROPHONE (OR HEADSET)	12
GETTING STARTED	13
VOICE OPERATED TRANSMISSION (VOX)	14
VOX GAIN	14
VOX OPERATION	16
KEY FUNCTIONS	17
CALL KEY	17
MONITOR KEY	17
BACKGROUND OPERATIONS	18
TIME-OUT TIMER (TOT)	18
LOW BATTERY WARNING	18
CHANNEL ANNUNCIATION	18
QUIET TALK (QT)/ DIGITAL QUIET TALK (DQT)	18
CHANNEL SETUP MODE	19
CHANNEL OPERATING FREQUENCIES	21
QUIET TALK (QT)/ DIGITAL QUIET TALK (DQT) SETTINGS	23
CHANNEL CONFIRMATION MODE	26
KEY ASSIGNMENT MODE	27
CALLING ALERT	29
KEY LOCK	30
MONITOR/ SQUELCH OFF	30
SCAN	31
SCRAMBLER	33
OPTIONAL ACCESSORIES	34
TROUBLESHOOTING GUIDE	35

UNPACKING AND CHECKING EQUIPMENT

Carefully unpack the transceiver. We recommend you identify the items listed in the following table before discarding the packing material. If any items are missing or have been damaged during shipment, file a claim with the carrier immediately.


SUPPLIED ACCESSORIES

Item		Part Number	Quantity
Battery charger (KSC-35)		W08-0988-XX	1
AC adapter	Type code E2	W08-0992-XX	1
	Type code T2	W08-0993-XX	1
Li-ion battery pack (KNB-45L)		W09-1033-XX	1
Speaker/ microphone jack cover		B09-0680-XX	1
Speaker/ microphone locking bracket		J19-5472-XX	1
Belt clip (KBH-10)		J29-0713-XX	1
Screw set		N99-2046-XX	1
Instruction manual		B62-1980-XX	1


Note: A type code (E2 or T2) can be found on the label attached to the package box.




Battery charger
(KSC-35)



AC adapter (E2)



AC adapter (T2)



Li-ion battery pack
(KNB-45L)



Speaker/ microphone
jack cover



Speaker/ microphone
locking bracket



Belt clip (KBH-10)




Screw set

ORIENTATION

Antenna

LED indicator

Indicates the transceiver status. Lights red while transmitting, green while receiving, and flashes red while the battery power is low while transmitting.



Channel selector

Rotate to change the operating channel from 1 ~ 16.

Power switch/ Volume control

Turn clockwise to switch the power ON and counterclockwise to switch the power OFF. Rotate to adjust the volume.

PTT (Push to Talk) switch



Press and hold, then speak into the microphone to transmit.

Call key

Press before making a call, to alert the other party members {page 17}.

Monitor key

Press and hold to hear background noise and listen for weak signals {page 17}.



Speaker/ microphone jacks

Battery pack (KNB-45L)

Note: The **Call** and **Monitor** keys can be reprogrammed {page 27}.

PREPARATION

BATTERY PACK PRECAUTIONS

Do not use battery packs or battery chargers not recommended by **KENWOOD**.



CAUTION

- ◆ Do not recharge the battery pack if it is already fully charged. Doing so may cause the life of the battery pack to shorten or the battery pack may be damaged.
- ◆ After recharging the battery pack, disconnect it from the charger. If the charger power is reset (turned ON after being turned OFF), recharging will start again and the battery pack will become overcharged.
- ◆ Do not use the transceiver while charging the battery pack. We recommend you switch the transceiver power OFF while charging is taking place.
- ◆ Do not charge the battery pack when the battery pack or transceiver is wet, to avoid the risk of fire or damage. Wipe the water from the battery pack or transceiver using a dry cloth before charging.
- ◆ Do not short the battery terminals or dispose of the battery by fire.
- ◆ Never attempt to remove the casing from the battery pack.

Information concerning the Li-ion battery pack:

The battery pack includes flammable objects such as organic solvent. Mishandling may cause the battery to rupture producing flames or extreme heat, deteriorate, or cause other forms of damage to the battery. Please observe the following prohibitive matters.



DANGER

- **Do not disassemble or reconstruct battery!**
The battery pack has a safety function and protection circuit to avoid danger. If they suffer serious damage, the battery may generate heat or smoke, rupture, or burst into flame.

**DANGER**

- **Do not short-circuit the battery!**

Do not join the + and – terminals using any form of metal (such as a paper clip or wire). Do not carry or store the battery pack in containers holding metal objects (such as wires, chain-necklace or hairpins). If the battery pack is short-circuited, excessive current will flow and the battery may generate heat or smoke, rupture, or burst into flame. It will also cause metal objects to heat up.

- **Do not incinerate or apply heat to the battery!**

If the insulator is melted, the gas release vent or safety function is damaged, or the electrolyte is ignited, the battery may generate heat or smoke, rupture, or burst into flame.

- **Do not use or leave the battery near fires, stoves, or other heat generators (areas reaching over 80°C/ 176°F)!**

If the polymer separator is melted due to high temperature, an internal short-circuit may occur in the individual cells and the battery may generate heat or smoke, rupture, or burst into flame.

- **Do not immerse the battery in water or get it wet by other means!**

If the battery's protection circuit is damaged, the battery may charge at extreme current (or voltage) and an abnormal chemical reaction may occur. The battery may generate heat or smoke, rupture, or burst into flame.

- **Do not charge the battery near fires or under direct sunlight!**

If the battery's protection circuit is damaged, the battery may charge at extreme current (or voltage) and an abnormal chemical reaction may occur. The battery may generate heat or smoke, rupture, or burst into flame.

- **Use only the specified charger and observe charging requirements!**

If the battery is charged in unspecified conditions (under high temperature over the regulated value, excessive high voltage or current over regulated value, or with a remodeled charger), it may overcharge or an abnormal chemical reaction may occur. The battery may generate heat or smoke, rupture, or burst into flame.

- **Do not pierce the battery with any object, strike it with an instrument, or step on it!**

This may break or deform the battery, causing a short-circuit. The battery may generate heat or smoke, rupture, or burst into flame.

**DANGER**

- **Do not jar or throw the battery!**

An impact may cause the battery to leak, generate heat or smoke, rupture, and/or burst into flame. If the battery's protection circuit is damaged, the battery may charge at an abnormal current (or voltage), and an abnormal chemical reaction may occur. The battery may generate heat or smoke, rupture, or burst into flame.

- **Do not use the battery pack if it is damaged in any way!**

The battery may generate heat or smoke, rupture, or burst into flame.

- **Do not solder directly onto the battery!**

If the insulator is melted or the gas release vent or safety function is damaged, the battery may generate heat or smoke, rupture, or burst into flame.

- **Do not reverse the battery polarity (and terminals)!**

When charging a reversed battery, an abnormal chemical reaction may occur. In some cases, an unexpected large amount of current may flow upon discharging. The battery may generate heat or smoke, rupture, or burst into flame.

- **Do not reverse-charge or reverse-connect the battery!**

The battery pack has positive and negative poles. If the battery pack does not smoothly connect with a charger or operating equipment, do not force it; check the polarity of the battery. If the battery pack is reverse-connected to the charger, it will be reverse-charged and an abnormal chemical reaction may occur. The battery may generate heat or smoke, rupture, or burst into flame.

- **Do not touch a ruptured and leaking battery!**

If the electrolyte liquid from the battery gets into your eyes, wash your eyes out with fresh water as soon as possible, without rubbing your eyes. Go to the hospital immediately. If left untreated, it may cause eye-problems.

**WARNING**

- **Do not charge the battery for longer than the specified time!**

If the battery pack has not finished charging even after the regulated time has passed, stop it. The battery may generate heat or smoke, rupture, or burst into flame



WARNING

- **Do not place the battery pack into a microwave or high pressure container!**
The battery may generate heat or smoke, rupture, or burst into flame.
- **Keep ruptured and leaking battery packs away from fire!**
If the battery pack is leaking (or the battery emits a bad odor), immediately remove it from flammable areas. Electrolyte leaking from battery can easily catch on fire and may cause the battery to generate smoke or burst into flame.
- **Do not use an abnormal battery!**
If the battery pack emits a bad odor, appears to have different coloring, is deformed, or seems abnormal for any other reason, remove it from the charger or operating equipment and do not use it. The battery may generate heat or smoke, rupture, or burst into flame.

■ Using the Li-ion Battery Pack

- Charge the battery pack before using it.
- To keep the battery discharge at a minimum, remove the battery pack from the equipment when it is not in use. Store the battery pack in a cool and dry location.
- When storing the battery pack for a long period:
 - 1 Remove the battery pack from the equipment.
 - 2 Discharge the battery pack, if possible.
 - 3 Store the battery pack in a cool (below 25°C/ 77°F) and dry location.

■ Characteristics of the Li-ion Battery Pack

- As the battery pack is charged and discharged repeatedly, the battery capacity decreases.
- Even if the battery pack is unused, the battery pack degrades.
- It takes a longer time to charge the battery pack in cooler areas.
- The life of battery pack is shortened when it is charged and discharged in hotter areas. When the battery pack is stored in a hot location, the battery pack degrades quicker. Do not leave the battery pack in vehicles or near heating appliances.
- When the battery pack operating time becomes short, even if it is fully charged, replace the battery pack. Continuing to charge and discharge the battery pack may result in electrolyte leakage.


CHARGING THE BATTERY PACK

The battery pack is not charged at the factory; charge it before use.

Average battery pack life (calculated using 5% transmit time, 5% receive time, and 90% standby time) is 20 hours.

ATTENTION: Always switch OFF a transceiver equipped with a battery pack before inserting the transceiver into the charger.

1




Plug the AC adapter cable into the jack located on the rear of the charger.

2

Plug the AC adapter into an AC outlet.

3



Slide a battery pack or a transceiver equipped with a battery pack into the charging slot of the charger.

- Make sure the metal contacts of the battery pack mate securely with the charger terminals.
- The indicator lights red and charging starts.

4 When charging is completed, the indicator lights green. Remove the battery pack or the transceiver from the charging slot of the charger.

- It takes approximately 3 hours to charge the battery pack.
- When the charger will not be used for a long time, unplug the AC adapter from the AC outlet.

Note:

- ◆ When the indicator blinks red, the battery pack is either defective or the battery pack contacts are not properly mated with those of the charger.
 - ◆ The ambient temperature should be between 5°C and 40°C (41°F and 104°F) while charging is in progress. Charging outside this range may not fully charge the battery.
 - ◆ The battery pack life is over when its operating time decreases even though it is fully and correctly charged. Replace the battery pack.
-


INSTALLING/ REMOVING THE BATTERY PACK



CAUTION


- ◆ Do not short the battery terminals.
- ◆ Do not dispose of the battery by fire.
- ◆ Never attempt to remove the casing from the battery pack.

1




Align the battery pack with the back of the transceiver, then press the battery pack and transceiver firmly together until the release latch on the base of the transceiver locks.

2




To remove the battery pack, lift the safety catch on the base of the transceiver, then press the release latch underneath the safety catch.

3



While pressing the release latch, pull the battery pack away from the transceiver.

INSTALLING THE BELT CLIP



If necessary, attach the belt clip using the two supplied 3 x 8 mm screws.


Note: If the belt clip is not installed, its mounting location may get hot during continuous transmission or when left sitting in a hot environment.



CAUTION

Do not use glue which is designed to prevent screw loosening when installing the belt clip, as it may cause damage to the transceiver. Acrylic ester, which is contained in these glues, may crack the transceiver's back panel.


INSTALLING THE COVER OVER THE SPEAKER/ MICROPHONE JACKS



If you are not using a speaker/ microphone, install the cover over the speaker/ microphone jacks using the supplied 3 x 6 mm screw.


Note: To keep the transceiver water resistant, you must cover the speaker/ microphone jacks with the supplied cover.

INSTALLING THE OPTIONAL SPEAKER/ MICROPHONE (OR HEADSET)



Insert the speaker/ microphone (or headset) plugs into the speaker/ microphone jacks.

Note: Always switch OFF the transceiver power when installing or removing a speaker/ microphone or headset.




Attach the locking bracket using the supplied 3 x 6 mm screw.

Note: The transceiver is not fully water resistant while using the speaker/ microphone.

GETTING STARTED


1



Turn the **Power** switch/ **Volume** control clockwise to switch the transceiver power ON.


- A beep sounds.

2



Press and hold the **Monitor** key to hear background noise, then rotate the **Power** switch/ **Volume** control to adjust the volume.


3



Rotate the **Channel** selector to select your desired channel.


- When you receive an appropriate signal, you will hear audio from the speaker.

4



To make a call, press and hold the **PTT** switch, then press the **Call** key to alert the other party members that you are making a call. Release the **Call** key to stop sending your alert tone.

5



Continue pressing the **PTT** switch, then speak into the microphone to transmit. Release the **PTT** switch to receive.

- The LED lights red while transmitting.
- For best sound quality, speak into the microphone in your normal voice while holding the microphone approximately 3 to 4 cm from your lips.

VOICE OPERATED TRANSMISSION (VOX)

Using the VOX feature, you can operate the transceiver hands-free. In order to use this feature, however, you must use an optional headset; VOX will not function with the built-in microphone. For best operating conditions, we recommend you use an optional headset with both an ear piece and a microphone on a boom that rests in front of your mouth.

With VOX activated, your voice level will determine when the transceiver transmits. Because of this, you must take care that the ambient noise around you is not so loud that it causes the transceiver to transmit. Due to the automatic switching between transmission and reception, we recommend you set the VOX Gain level such that it will not activate transmission when in an area with excessive ambient noise.

VOX GAIN

To activate the VOX function and set the VOX Gain level:

1



With the transceiver power OFF, connect the headset to the transceiver {page 12}.

- The VOX function does not activate when a headset is not connected to the speaker/ microphone jack of the transceiver.


2



Press and hold the **Call** key while turning the transceiver power ON.

- Continue to hold the **Call** key until the LED lights orange and the transceiver announces "VOX", then release the key. Upon releasing the key, the transceiver will announce the current VOX Gain level.


3



Press the **Call** key to increase the VOX Gain level and the **Monitor** key to decrease the level.

- The VOX Gain can be adjusted from level 1 to level 10 and OFF.
- The transceiver announces the VOX Gain level as you adjust it. If OFF is selected, the transceiver announces "Off".


4



Press the **PTT** switch within 5 seconds to save the setting, otherwise the operation will cancel.

- A beep will sound and the transceiver will announce the new VOX Gain level.

5



Turn the transceiver power OFF and then ON again to activate VOX.

Note:

- ◆ VOX Gain level 1 is the least sensitive and VOX Gain level 10 is the most sensitive.
- ◆ If a speaker/ microphone is connected to the transceiver while the VOX function is switched ON and the VOX Gain level is configured to a higher, more sensitive level, louder received signals may cause the transceiver to start transmission.
- ◆ The transceiver will automatically return to normal operation if no action is performed for 5 seconds.

VOX OPERATION

1 Set up a VOX Gain level from 1 to 10 {page 14}.

2 To transmit, simply speak into the headset microphone.

- You do not need to press the **PTT** switch; the transceiver automatically detects your voice and begins transmitting.

3 To stop transmitting, stop speaking.

- Transmission will continue momentarily after you stop speaking, so ensure your transmission will not be cut off.

4 To deactivate the VOX function, set the VOX Gain level {page 14} to OFF.

Note:

- ◆ While transmitting via VOX, all keys other than power OFF are disabled.
 - ◆ When you operate the VOX function, you must use an optional KHS-1 or KHS-21 accessory.
 - ◆ VOX will not operate when the battery level becomes too low. (The LED will flash red in this state.)
-

KEY FUNCTIONS

CALL KEY

The default function of the **Call** key is Calling Alert.

Calling alert tones are used to identify yourself to your party members and inform them that you are about to make a call. Your dealer can set up your transceiver with 1 of 10 different calling alert tones. If each party member uses a different calling alert tone, it is easy to know who is making the call.

To make a call using the calling alert tone, press and hold the **PTT** switch, then press the **Call** key.

- The calling alert tone will transmit for the duration you press the **Call** key.

MONITOR KEY

The default function of the **Monitor** key is Squelch Off Momentary.

When no signals are present, the squelch on the transceiver automatically mutes the speaker so you will not hear background noise. Using the Monitor key, you can disable the squelch to unmute the speaker at any time. This feature is useful for a variety of reasons:

- It allows you to confirm the channel activity so you don't make a call while another party is using the same channel.
- It allows you to adjust the volume level without having to wait for a call.
- When receiving a call that is intermittent due to a weak signal, disabling the squelch will allow you to listen to the call without it continuously cutting out.

To manually deactivate the squelch, press and hold the **Monitor** key.

To return to normal operation, simply release the **Monitor** key.

TIME-OUT TIMER (TOT)

The purpose of the Time-out Timer is to prevent you from using a channel for an extended period of time. This function is useful, for example, when you accidentally keep the **PTT** switch pressed. Additionally, by limiting the amount of time you can continuously transmit, this feature helps you save on battery power consumption.

If you continuously transmit for 60 seconds (default), the transceiver will stop transmitting and an alert tone will sound. To stop the tone, release the **PTT** switch. You can press the **PTT** switch again to resume transmitting.

LOW BATTERY WARNING

Low Battery Warning alerts you when the battery needs to be recharged or replaced.

While operating the transceiver, if the battery power becomes low, an alert tone will sound every 30 seconds and the LED indicator will blink red. Replace or recharge the battery pack at this time.

CHANNEL ANNUNCIATION

When changing the channel, the transceiver will announce the selected channel number after you stop changing the channel. Likewise, the transceiver will announce the current channel after you turn the transceiver power ON. (Channel Annunciation can be activated or deactivated by your dealer.)

QUIET TALK (QT)/ DIGITAL QUIET TALK (DQT)

Quiet Talk (QT) and Digital Quiet Talk (DQT) are functions that reject signals from undesired parties that are using the same channel as you. You will hear audio from the speaker only when you receive a signal that contains a QT tone or a DQT code that matches the one set up on the channel you are using. If a call containing a different tone or code is made on the same channel you are using, squelch will not open and you will not hear the call. Likewise, when you transmit on a channel set up with QT or DQT, the receiving station must have a matching tone or code in order to hear your call.

Although it may seem like you have your own private channel while using QT or DQT, other parties can still hear your calls if they set up their transceiver with the same tone or code.

The default QT/DQT settings for each channel are provided in the table on page 20.

CHANNEL SETUP MODE

This transceiver allows you to reprogram each of the channels with different frequencies and Quiet Talk/ Digital Quiet Talk settings. The table below lists the default channel settings.


Channel Number	Table Number	Frequency (MHz)	Tone Number	QT/DQT Setting
1	1	446.00625	10	94.8 Hz
2	8	446.09375	08	88.5 Hz
3	3	446.03125	13	103.5 Hz
4	6	446.06875	05	79.7 Hz
5	4	446.04375	17	118.8 Hz
6	2	446.01875	18	123.0 Hz
7	7	446.08125	19	127.3 Hz
8	5	446.05625	07	85.4 Hz
9	1	446.00625	14	107.2 Hz
10	8	446.09375	15	110.9 Hz
11	3	446.03125	16	114.8 Hz
12	6	446.06875	06	82.5 Hz
13	4	446.04375	27	D132N
14	2	446.01875	28	D155N
15	5	446.05625	29	D134N
16	7	446.08125	30	D243N

Note: If you do not select an operating frequency for a channel, you will not be able to select a Quiet Talk/ Digital Quiet Talk setting for that same channel.

CHANNEL OPERATING FREQUENCIES

To change the operating frequency of a channel:

1



With the transceiver power OFF, press and hold the **PTT** switch and **Call** key while turning the transceiver power ON.


- Continue to hold the **PTT** switch and **Call** key until the LED lights orange and the transceiver announces "Self".

2

Release the **PTT** switch and **Call** key.

- The transceiver announces "Channel".


3



Press and release the **PTT** switch, then rotate the **Channel** selector to your desired channel.

- Upon pressing and releasing the PTT switch, a beep will sound and the transceiver announces "Table zero".


4



Press the **Call** key to increment the Table number or the **Monitor** key to decrement the number, to select the new channel frequency.

- Table numbers and their corresponding operating frequencies are provided in the table on page 22.
- A voice announcement will inform you of the currently selected Table number.


5



Press the **PTT** switch within 5 seconds to save the setting, otherwise the operation will cancel.

- A beep will sound.
- Repeat steps 3 to 5 to set up another channel.

6



Turn the transceiver power **OFF** and then **ON** again to activate the new settings.

Note: The transceiver will automatically return to normal operation if no action is performed for 5 seconds.

Table Number	Operating Frequency	Table Number	Operating Frequency
0	—		
1	446.00625 MHz	5	446.05625 MHz
2	446.01875 MHz	6	446.06875 MHz
3	446.03125 MHz	7	446.08125 MHz
4	446.04375 MHz	8	446.09375 MHz

QUIET TALK (QT)/ DIGITAL QUIET TALK (DQT) SETTINGS

To change the QT/DQT settings of a channel:

1



With the transceiver power OFF, press and hold the **PTT** switch and **Call** key while turning the transceiver power ON.


- Continue to hold the **PTT** switch and **Call** key until the LED lights orange and the transceiver announces "Self".

2

Release the **PTT** switch and **Call** key.

- The transceiver announces "Channel".


3



Press the **Call** key or **Monitor** key to select QT/DQT setup.

- The transceiver announces "Tone".


4



Press and release the **PTT** switch, then rotate the **Channel** selector to your desired channel.

- Upon pressing and releasing the PTT switch, a beep will sound and the transceiver announces "Tone one".


5



Press the **Call** key to increment the Tone number or the **Monitor** key to decrement the number, to select the new tone or code.

- Tone numbers and their corresponding tones/ codes are provided in the table on page 25.
- Press and hold the **Call** or **Monitor** key to increment/ decrement the Tone number by 5 at a time.
- A voice announcement will inform you of the currently selected Tone number.


6



Press the **PTT** switch within 5 seconds to save the setting, otherwise the operation will cancel.

- A beep will sound.
- Repeat steps 4 to 6 to set up another channel.

7



Turn the transceiver power **OFF** and then **ON** again to activate the new settings.

Note: The transceiver will automatically return to normal operation if no action is performed for 5 seconds.


Tone Number	QT/DQT Setting	Tone Number	QT/DQT Setting	Tone Number	QT/DQT Setting
1	67.0 Hz	14	107.2 Hz	27	D132N
2	71.9 Hz	15	110.9 Hz	28	D155N
3	74.4 Hz	16	114.8 Hz	29	D134N
4	77.0 Hz	17	118.8 Hz	30	D243N
5	79.7 Hz	18	123.0 Hz	31	D311N
6	82.5 Hz	19	127.3 Hz	32	D346N
7	85.4 Hz	20	131.8 Hz	33	D315N
8	88.5 Hz	21	136.5 Hz	34	D351N
9	91.5 Hz	22	141.3 Hz	35	D423N
10	94.8 Hz	23	146.2 Hz	36	D664N
11	97.4 Hz	24	151.4 Hz	37	D431N
12	100.0 Hz	25	156.7 Hz	38	D723N
13	103.5 Hz	26	162.2 Hz	Off	OFF

Note: The QT/DQT settings can be changed by your dealer.

CHANNEL CONFIRMATION MODE

To confirm your channel settings:

1



With the transceiver power OFF, press and hold the **PTT** switch while turning the transceiver power ON.


- Continue to hold the **PTT** switch until the LED lights orange and the transceiver announces “Channel Confirm”.

2

Release the **PTT** switch.

- The transceiver announces the channel Table number and Tone number of the current channel.

3



Rotate the **Channel** selector to your desired channel within 5 seconds, otherwise the operation will cancel.

- The transceiver announces the channel Table number and Tone number of the selected channel.

Note: The transceiver will automatically return to normal operation if no action is performed for 5 seconds.


KEY ASSIGNMENT MODE

This transceiver allows you to reprogram the **Call** and **Monitor** keys with any of the functions listed in the table below. Explanations on the use of each function are provided on the following pages.

Table Number	Function Name
0	None (no function)
1	Calling Alert (Call key default)
2	Key Lock
3	Key Lock Status Memory
4	Monitor
5	Monitor Momentary
6	Scan
7	Scan + Temporary Delete
8	Scrambler
9	Squelch Off
10	Squelch Off Momentary (Monitor key default)
11	Temporary Delete

To change the functions of the **Call** and **Monitor** keys:


1



With the transceiver power OFF, press and hold the **Call** and **Monitor** keys while turning the transceiver power ON.

- Continue to hold the **Call** and **Monitor** keys until the LED lights orange and the transceiver announces "Setup".

2




Continue to press and hold the key to be reprogrammed (either the **Call** key or the **Monitor** key), while releasing the remaining key.

- The transceiver will announce "Table zero" {page 27}.
- If you continue to hold both keys, or if you release both keys, the operation will cancel in 5 seconds.

3

Release the key.


4



Press the **Call** key to increment the Table number or the **Monitor** key to decrement the number, to select the new key function

- Table numbers and their corresponding functions are provided in the table on page 27.
- A voice announcement will inform you of the currently selected Table number.


5



Press the **PTT** switch within 5 seconds to save the setting, otherwise the operation will cancel.

- A beep will sound and the transceiver will announce the new Table number.

6



Turn the transceiver power **OFF** and then **ON** again to activate the new settings.

Note: The transceiver will automatically return to normal operation if no action is performed for 5 seconds.

CALLING ALERT

Calling alert tones are used to identify yourself to your party members and inform them that you are about to make a call. Your dealer can set up your transceiver with 1 of 10 different calling alert tones. If each party member uses a different calling alert tone, it is easy to know who is making the call.

To make a call using the calling alert tone, press and hold the **PTT** switch, then press the key programmed as **Calling Alert**.

- The calling alert tone will transmit for the duration you press the **Calling Alert** key.

KEY LOCK

Press and hold the key programmed as **Key Lock** for 1 second to lock/ unlock the transceiver keys. The following keys/ functions can still be used when Key Lock is active: Calling Alert, Key Lock, Monitor, Monitor Momentary, PTT, Squelch Off, Squelch Off Momentary, and Volume.

If the key is programmed as **Key Lock Status Memory**, when the transceiver power is turned OFF and then ON again, the keys remain locked. Otherwise, when the transceiver power is turned OFF and then ON again, the Key Lock function will be cancelled.

MONITOR/ SQUELCH OFF

You can use the key programmed as **Monitor** or **Squelch Off** to listen to weak signals that you cannot hear during normal operation, to deactivate channel signaling, and to adjust the volume when no signals are present on your selected channel.

- **Monitor:** Momentarily press to deactivate Quiet Talk or Digital Quiet Talk signaling. Press the key again to return to normal operation.
- **Monitor Momentary:** Press and hold to deactivate Quiet Talk or Digital Quiet Talk signaling. Release the key to return to normal operation.
- **Squelch Off:** Momentarily press to hear background noise. Press the key again to return to normal operation.
- **Squelch Off Momentary:** Press and hold to hear background noise. Release the key to return to normal operation.

Note: The default Squelch level is set to 5 (out of 10). This value can be adjusted by your dealer.

SCAN

Scan is useful for monitoring signals on the transceiver channels. When scanning, the transceiver checks for a signal on each channel and only stops if a signal is present. If the QT/DQT matches, the transceiver stops at the channel and opens the squelch so you can listen to the call. If the QT/DQT does not match, the call is ignored and scanning continues.

Note: You can only use Scan if there are at least 2 channels available on your transceiver that are not locked out of Scan.

To start scanning, momentarily press the key programmed as either **Scan** or **Scan + Temporary Delete**.

- The LED indicator flashes green and scanning starts from the current channel and ascends through the channel numbers.
- When a signal is detected on a channel and the QT/DQT matches, scan pauses at that channel and the LED indicator lights green.
- When the signal is no longer present, scanning continues after 3 seconds (default).

To end Scan, press the **Scan** or **Scan + Temporary Delete** key again.

■ Priority Scan

The Priority channel is a channel that is given first priority to while scanning. The Priority channel is set by your dealer.

During Scan, the transceiver will automatically change to the Priority channel when a call is received on it, even if a call is already being received on any of the other channels.

■ Temporary Delete

You can temporarily remove specific channels from the scanning sequence during Scan. When Scan pauses at a channel, you can remove that channel from the scanning sequence by pressing and holding the key programmed as **Temporary Delete** for 1 second or **Scan + Temporary Delete** for 3 seconds.

- You cannot remove a channel if there will be less than 2 channels available for scanning remaining.
- To add the removed channels back into the Scan list, simply exit Scan mode or switch the transceiver power OFF and then ON again.

■ Revert Channel

During Scan, pressing the **PTT** switch will automatically select the transceiver's Revert channel and you will begin transmitting. Your dealer can program the Revert channel using one of the following methods:

- **Selected:** The last channel selected prior to scanning is assigned as the Revert channel.
- **Selected + Talkback:** The last channel selected prior to scanning is assigned as the Revert channel. However, the transceiver also transmits on the channel where Scan is currently paused. This is the default Revert channel setting.
- **Priority:** If your dealer has programmed a Priority channel, it is the Revert channel.
- **Priority + Talkback:** If your dealer has programmed a Priority channel, it is the Revert channel. However, the transceiver also transmits on the channel where Scan is currently paused.

SCRAMBLER

Whereas the Quiet Talk and Digital Quiet Talk functions {page 19} allows you to ignore unwanted calls, Scrambler allows you to hold a conversation in complete privacy. When activated, any other party listening in on your channel will be unable to understand your conversation. The transceiver scrambles your voice so that anybody listening to your conversation will not be able to understand what you are saying.


In order for members of your own group to understand your call while you are using the Scrambler, all other members must also activate the Scrambler on their transceivers. This scrambles everybody's voice while transmitting and unscrambles the voice message on your own transceiver when you receive the message.

To activate the Scrambler, press the key programmed as **Scrambler**.


To deactivate the Scrambler, press the **Scrambler** key again.

OPTIONAL ACCESSORIES


KMC-17 (Speaker/ microphone)



KMC-21 (Speaker/ microphone)




KHS-1 (Headset)



KHS-21 (Headset)



KWR-1 (Water resistant bag)



TROUBLESHOOTING GUIDE

Problem	Solution
Cannot turn the transceiver power ON.	<ul style="list-style-type: none">• The battery pack may be dead. Recharge or replace the battery pack.• The battery pack may not be installed correctly. Remove the battery pack and install again.
Battery power dies shortly after charging.	<ul style="list-style-type: none">• The battery pack life is finished. Replace the battery pack with a new one.
Cannot talk to or hear other members in your group.	<ul style="list-style-type: none">• Make sure you are using the same frequency and QT/DQT settings as the other members in your group.• Other group members may be using the Scrambler function. Turn on your transceiver's Scrambler.• Other group members may be too far away. Make sure you are within range of the other transceivers.
Other voices (besides group members') are present on the channel.	<ul style="list-style-type: none">• Change the QT/DQT settings. Make sure all group members change the settings on their transceivers to match the new QT/DQT setting.